



Making vehicles special

All Terrain Ambulance: The New WAS 4x4.



The New WAS 4x4: All Terrain and Off-Road Special Ambulance for Highest Standards.



SHORT DESCRIPTION

With its special off-road ABS and its 4Motion all-wheel drive, this compact ambulance vehicle grips on nearly any terrain. Using modern manufacturing techniques, this box body conversion with its extended roof spoiler offers perfect solutions for individual requirements. The integrated warning system in LED technology ensures a better visibility in all traffic conditions. The internal lighting, the external flood lights and the additional rear lights are also LED technology – thus offering perfect working conditions with maximum energy efficiency. The large side sliding windows and the reverse camera with monitor screen provide a perfect all-round visibility.

BOX BODY

Modell	WAS 4x4
Internal dimensions	Length: 2280 mm
	Width: 1170 mm
	Height: 1405 mm
Doors	Double rear wing doors

EXTERIOR

Robust construction 4x4 using the WAS VacuTherm® method

Large obscured sliding windows left-hand side and right-hand side

LED front flashers in the radiator grille

Integrated installation of acoustic warner

Foldable rear step for easy access

Tow bar

INTERIOR

Large storage compartments on the left-hand and the right-hand side walls to accommodate the equipment

INTERIOR

Airline rails in the floor fixing the stretcher support
Stretcher support with storage compartment, available in different sizes

Attendant seat at the bulkhead, crash-tested according to ECE R14

LED internal lighting with emergency light function and blue trauma light

Oxygen supply

Floor covering made of industrial PVC material, slip-proof and resistant to disinfection, with highest abrasion class

Dash board with console to accommodate the control panels

12V/230V power supply

230V charging system

12V/230V central electric system, easily accessible on the bulkhead (driver's cab side)

Preparation for radio equipment, analogue or digital

Preparation for mobile phone technology

Reverse camera with monitor screen in the rear-view mirror

Semi-automatic air conditioning

(according to base vehicle equipment)

Programmable additional water heating

(according to base vehicle equipment)

SPECIAL FEATURES

Removable stretcher support – the vehicle can be used alternatively as a material transport vehicle or a supply vehicle

Roof rack, material can be loaded from the floor (option)

Universal platform with telescopic ladder (option)

Under-voltage protection to ensure a permanent availability



With the swing-away frame structure, material can be easily loaded from either the right or the left side of the vehicle.



The right-hand and the left-hand side walls are equipped with large storage compartments. Robust air line rails in the floor fix the stretcher support or even material to be transported. The attendant seat is retractable to have an optimum use of space.

The New WAS 4x4: A Versatile Ambulance Vehicle for Any Terrain.

BASE VEHICLE

Model	VW Amarok
Type	DoubleCab
Engine power	132 kW/180 hp
Transmission	4Motion 6-shift-manual/automatic
Features	<ul style="list-style-type: none"> • Extra high clearance for off-road use • Additional air suspension on the rear axle (WAS) • Special off-road tyres 245/65/R17 with aluminium rims
Drive	Rear-wheel drive, selectable all wheel drive
Wheel base	3095 mm
Maximum total weight	3040 kg



After removing the stretcher support, in just a few simple steps, the spacious interior can be loaded with material.



Integrated heavy-duty drawer for the accommodation of scoop, spine board or rescue tools.



The stretcher support is swung down to a lower loading level, to ensure the safer loading of the patient.

The concept is transferable to other vehicle types. The equipment is an example and can be adapted to your requirement.

